



# -/IGUILI\220

## **EN** User Manual

2015-03-30, Revision A
Translation of the original user manual



**NESPRESSO** 

## Content

General Information	
Safety Warnings	
General Safety Instructions	
Machine Overview	
Packaging Contents	
Refrigerator Overview	
Operating Overview	
NESPRESSO Grand Cru Recommendation	
First Use	
Energy Saving Mode	
Maximum Energy Saving Mode	
Coffee Preparation	
Milk-Based Coffee Recipes	
Milk Preparation	
Hot Water Preparation	
Daily Cleaning	
Weekly Cleaning	
Menu Settings	
- Language setting	
- Statistics	
- Navigation	
- Milk parameter	
- Cup heater	
- AGUILA+ button programming	
Alarms / Notifications	
Specifications	
EC-Declaration	
Type Plate	
Impressum	

#### **General Information**

## Important!

Read these instructions carefully before use and keep it in a safe place for further reference.

Improper use of the machine releases *Nespresso* from any liability.

#### **Summary**

This user manual describes the operating instructions for the AGUILA 220 espresso coffee machine and is delivered with the machine.

## **Personnel Requirements**

Only the listed personnel - if trained - is authorized to use the AGUILA 220 espresso coffee machine.

#### Service partner

 Your service partner is a Thermoplan representative. If you have any questions or problems, first contact a Nespresso representative.

#### Trained technician

 Trained technicians are employees trained and certified by Thermoplan, who sell and maintain Thermoplan products.

#### Trained operator staff

 Trained operator staff are employees who were briefed and trained in the use of the coffee machine (reading of the instruction manual) and who are able to operate the machine and execute the maintenance steps described in this manual.

#### Operation

This machine is only suitable for producing coffee, milk and hot water products and is suitable for commercial use in the catering trade. Therefore, please take note of the following instructions:

- This machine works with Nespresso capsules, available exclusively through Nespresso and its authorized distributors.
- The milk container must only be used to store cold milk. Do not fill the milk container with any liquids other than milk (e.g. syrup or alcohol). Please note that when pouring the milk into the milk container it must have a temperature of below 5 °C, as the refrigerator has been designed to keep the milk cool but not to lower its temperature.
- Carry out all necessary maintenance work as described in these instructions at regular intervals.
- The machines must only be operated by trained operator staff.
- All operations other than those mentioned in this manual must only be performed by authorized and trained service partners of Thermoplan.

 The capsules container must be emptied when the corresponding notification appears on the display. Rinse the container with a solution of warm, soapy water.

#### Cleaning the machine

Cleaning the machine on a daily basis is an absolute must, as it guarantees necessary hygiene and food safety, perfect *Nespresso* grand cru taste as well as a longer life of the machine.

Please refer to chapter "Daily cleaning" for a complete guide to successfully clean your machine. Also take note of the following instructions:

- Use only the Thermoplan milk cleaning tablets to perform the automatic cleaning process. Do not use any other cleaning detergent or disinfection agent for this purpose.
- When touching the coffee machine, in particular the spouts, bacterial contamination must be avoided.
- Cloths or sponges must be wrung out thoroughly to ensure that they are only moist, not wet, otherwise there is a risk of electric shock.
- Plastic parts must not be dried in the microwave.
- Do not clean plastic parts with alcohol, ethanol, methanol, methylated spirits or disinfectants. Detergents with strong acid agents such as acetic acid must also not be used.
- The machine must not be cleaned with water jets.
- The milk suction tube with temperature sensor and level sensor, as well as all internal parts of the refrigerator, cleaning key, coffee outlets shall be cleaned only with single-use tissue or paper towel. Clothes used to clean external parts of the machine shall be properly treated to prevent possible bacterial contamination.

#### Machine hygiene

 Frequent automated rinsing (internally and externally) takes place to sustain high hygiene standards throughout the machine life time.

#### **Commercial use**

 This machine is intended to be used by experts or trained users in shops, light industry and on farms.

#### General Information

#### Maintenance work

 A notification will appear on the coffee machine display if the machine needs to be serviced. The machine must be serviced by authorized and trained service partners of Thermoplan at least once every year or every 24'000 product beverages.

#### Disposal

 An authorized and trained service partner of Thermoplan has to dispose of the machine and its packaging. Do not dispose of the machine or its components yourself.

## Limitations of liability

- Thermoplan accepts no liability for any injuries or accidents if the safety instructions covered in this manual are not adhered to. Additionally, liability is only accepted within the boundaries of the machine. Thermoplan shall be liable for faults on the machine in accordance with the warranty regulations.
- The manufacturer cannot be held liable for any damage caused by misuse or inappropriate handling of the machine.

## **Warranty regulations**

- The machine is covered by 2 years manufacturer's warranty from the date of installation.
- Malfunctions due to misuse or connecting unsuitable connections shall not be compensated.
- Wear and tear parts are not covered by any warranty.
- Each warranty claim must be recorded by a corresponding Nespresso Thermoplan service partner using a fully completed form that is submitted to Thermoplan.
- Thermoplan reviews the claims, issues RMA numbers to them and informs the affected reseller which spare parts need to be returned.
- All Nespresso machines must pass stringent controls. Reliability tests under practical conditions are performed randomly on selected units. This can show traces of any previous use.

#### **General Notes:**

#### Risk of material damage

- Wrong handling of the machine could lead to property damage.
- The machine is for indoor use only.
- Clean machine before taking out of service for a longer period of time. Remove and empty capsules container, disconnect machine from the mains. Remove and empty milk container, clean and store with lid open. Leave refrigerator door open.
- Ambient temperature must be between 16 °C and 32 °C.
- Position machine on a flat, horizontal, stable and heat-resistant surface
- Do not position machine where a water jet could be used to clean.
- Leave a gap of at least 50 mm in front of air vents.
- Store machine in dust free and dry environment, always at a temperature above 0 °C.
- The top of the machine must be at least 1.5 m above the floor.
- Place machine 20 cm or further away from the user.
- Use Thermoplan cleaning accessories only.
- Never use the machine without drip grid.
- The manufacturer does not accept any liability for consequences arising from both internal and external modifications on the machine
- Do not store explosive substances such as aerosol cans with a flammable propellant inside the appliance.
- Never use the cup heater for drying wet cups; risk of electric shock.
- $\bullet$  Always place cups upside-down to ensure good heat transmission.

## **Safety Warnings**

#### Structure

The safety instructions in this document are structured as following:



- 1 Safety sign2 Safety signal word
- 5 Specified safety si
- 3 Source 6 Prevention

#### Safety signal words

The following warning messages are used in the present manual:





#### Hint

adresses practices that help the reader to use the equipment properly.

### Safety signs

The following safety signs are used in this manual:

<u> </u>	The warning triangle appears where nonadherence to the safety instructions may result in risks to the user or the machine.
<u> </u>	Warning:
<u></u>	Electric shock
$\wedge$	Warning:
<u></u>	Risk of scalding
$\wedge$	Warning:
	Risk of bruising
	Instruction:
	Wear gloves
<u> </u>	Instruction:
	Wear goggles
i	General information

## **Working Area**

- Keep your workspace clean and tidy. Disorder and unlit workspaces can lead to accidents.
- The machine must only be operated in a hygienic and ergonomic environment. The user must have sufficient space and the working area must be well lit.

# **General Safety Instructions**

## **General Safety Notes**

- In the event of emergency, switch off the machine using the main switch. Unplug the machine or remove the fuse from the fuse box. Contact your service partner.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Children are not permitted to clean and perform maintenance on the machine without supervision.
- The access to the service area is allowed to trained service personnel and instructed personnel only.

# General Safety Messages WARNING:

## Risk of electric shock

Contact with electrical components during

operation of the machine could result in death or serious injury.

- Do not open casing under any circumstances.
- Keep the machine away from moisture.
- Never immerse the machine, cable or plug in water or any other liquid.
- Immediately stop using the machine if cable or plug are damaged.
- Do not position the machine or cable near or on hot parts of the machine. Using the machine near open flames is strictly prohibited.
- Protect the cable from sharp edges.
- Do not reach up inside the inner casing when the capsules container is removed.
- Have the machine installed, relocated, removed, repaired or maintained by authorized, trained service staff and with genuine spare parts only.
- The machine and its supply cables must be positioned out of the reach of children.

## **General Safety** Instructions

## **CAUTION:**

## Risk of scalding

Contact with hot fluids could result in minor • If a capsule is blocked in the capsule or moderate injury.

- Do not handle underneath the product outlet.
- Avoid direct contact with hot fluids.
- Do not touch any dispenser before or after a beverage is being dispensed.
- Do not open the lever while a product is being dispensed or the machine is being cleaned.
- Empty the drip tray with caution.

## Risk of bruising

Handling inside the machine could result in minor or moderate injury.

- Do not open lever during preparation. To stop preparation, press the same product button again.
- Do not put fingers into the capsule insertion slots.

insertion slot, switch off machine before any operation.

## Risk of food intoxication

Ingestion of contaminated food could result in death or serious injury.


- Only use food with a sell-by date that has not yet expired.
- Store food in suitable locations.
- Clean the machine periodically and in accordance with the user manual.
- Only use heat treated (e.g. pasteurised or ultra heat treated) milk.
- Observe hygiene standards while pouring milk into the container.
- Only pour milk that has already been cooled down (below 5 °C) into the milk container.
- Use opened milk containers within 24 hours.

#### **Machine Overview**

## **Packaging Contents**

The following components are included in the delivery:

- Machine
- Milk container with cover
- User manual in English
- Thermoplan cleaning tablets
- Extraction tool for coffee outlets
- Water filter & head
- Water tube to connect main water inlet



- 1 Capsule insertion slots
- 2 Cup heater
- 3 Leve
- 4 Energy saving mode button (behind capsule container)
- 5 Hot water outlet
- 6 Coffee outlet
- 7 Used capsules container (capacity 130 capsules)
- 8 Drip grid / Drip tray

- Orip grid for small cups
- 10 Main switch (underneath)
- 11 Coffee outlet
- 12 Milk outlet
- 13 Milk container with cover
- 14 Thermoplan cleaning tablets
- 15 Extraction tool for coffee outlets

## **Refrigerator Overview**



Always fill milk container with cold milk (below 5 °C).



- 1 Cleaning key
- 2 Milk container cover
- 3 Milk container (max. 5 l)
- 4 Milk suction tube with temperature sensor and level sensor

## **Operating Overview**





Hot water

#### Coffee preparation buttons:



Ristretto



spresso





ungo

Beverage selection:

1

To view the name of the product on the display, press product button for 5 sec. To exit, wait 10 sec. without pressing any button.





#### Milk and milk foam buttons:



Hot milk foam



Hot milk



Cold milk foam

## Milk-based coffee recipes buttons:



AGUILA + (refer to user menu settings)



Espresso Macchiato



Cappuccino



Latte Macchiato



Iced Macchiato

#### **Coffee preparation buttons:**



Ristretto




Espresso



ungo

## NESPRESSO Grand Cru Recommendation

Each Grand Cru, even with a delicate and subtle character when black, develops new dimensions when combined with milk. This creates an almost infinite palette of taste variations. The *Nespresso* Grand Cru recommendation is based on the products' aromatic profile, as well as the mode of preparation of the respective recipes for an optimum experience.



#### Lungo Origin Guatemala Espresso Decaffeinato Ristretto Origin India Espresso Origin Brazil Lungo Decaffeinato Ristretto Intenso Espresso Leggero Lungo Leggero Cortado Lungo 0 Cortado Flat white Cappuccino Lungo S **(1)** Cappuccino Chiaro Cappuccino Freddo **Iced Cappuccino** V **Latte Grande (1) (2) (6)** Latte **Latte Piccolo** Iced Latte N Macchiatissimo

## **Cup Description**

٩	Espresso cup
	Lungo cup
S	Cappuccino cup
•	300 ml recipe glass
	350400 ml recipe glass
	500 ml take away cup

## First Use



## **⚠ CAUTION**

#### Risk of bruising

Handling inside the machine could result in minor or moderate injury.


Do not put fingers into the capsule insertion slots.



Switch-on facility main water supply.



The main switch is located underneath the



Close both levers.



Press any button.



Machine performs a cold start rinse (display shows a counter of 3 min.).





Machine heats up. All buttons flash in white. When the machine has heated up, all buttons will be permanently lit in white.



During rinsing the noise level

#### First Use

## **⚠ CAUTION**

#### Risk of food intoxication

Ingestion of contaminated food could result in minor or moderate injury.




Only use heat treated (e.g. pasteurised or ultra heat treated) milk.

Observe hygiene standards while pouring milk into the container.

Use opened milk container within 24 hours.



Open both levers.



Thoroughly clean the milk container and cover with a commercially available foodsafe household cleaner.



Carefully wipe milk suction tube with temperature sensor and level sensor, using only singleuse disposable tissue or paper towel.

### **⚠ CAUTION**

#### Risk of food intoxication

Usage of non-disposable tissue or sponge can lead to bacterial contamination of the milk




Use only single-use disposable tissue or paper towel to wipe milk suction tube with temperature sensor and level sensor.



To clean the outside of the machine, refer to external cleaning ( $\triangleright$  see page 23).







Insert milk suction tube with temperature sensor and level sensor through cover into the milk container.

The ideal temperature for foaming milk is 5 °C (if the milk temperature is above 6 °C, the foam quality will be reduced significantly).

The milk variety has an influence on foam quality. When switching from pasteurised to UHT milk, it may be necessary to adjust the milk foam settings (>> see page 28).


Most suitable quality for foaming milk is UHT milk. Pasteurized milk is more difficult to foam.

## **Energy Saving Mode**

The machine switches to energy saving mode after 30 min. of nonuse. All buttons appear white.

Press any button to return the machine to operating mode.






# Maximum Energy Saving Mode



After four hours of non-use, the machine switches to maximum energy saving mode. Press energy saving button to restart machine.







"Maximum energy saving mode" can be activated by pressing the button for 3 sec.

## **Coffee Preparation**



Ristretto



Espresso



Lungo



Coffee heads can be used simultaneously to prepare coffee.



Pull down drip grid for small cups.




Choose preferred Nespresso Grand Cru.

0000

000 000



Pull down lever to the lowest position.



Choose cup size desired (example Espresso).



Product name is displayed during prepara-



See *Nespresso* Grand Cru recommendation on page 12.

## **Coffee Preparation**

#### Top up / stop products

All product preparations can be stopped by pressing the product button again.

a

To top up your drink with some more beverage, press the product button within 1 min. after the end of product preparation.

Press product button again to stop.







Top up or stop product dispensing within

Ready →

12

◆ Ready



By pulling up the lever, the used capsule is ejected.



Machine is ready for next beverage.



## Milk-Based Coffee Recipes



Espresso Macchiato



Cappuccino



Latte Macchiato



Iced Macchiato



AGUILA+




For milk-based coffee recipes, place your cup under the right hand-side outlet.


Do not remove your cup until display shows "Ready" again. Some products have a brief pause between milk and coffee dispensing.

Sequence of dispensing may vary depending on the product.











Pull down lever to the lowest position.



Choose desired milk-based coffee recipe (example Cappuccino).





Coffee preparation starts.

## Milk-Based Coffee Recipes



Foaming milk preparation according to chosen product.



By pulling up the lever, the used capsule is ejected.



#### Milk system rinsing

The milk system is rinsed automatically in order to ensure high hygiene standards

# **△ CAUTION**

## Risk of scalding

The milk system will be rinsed automatically 5 min. after the preparation of a milk-based beverage.

Duration approx. 10 sec. Avoid direct contact with hot water.

Protect hands from scalding.



Automatic internal rinsing: An approx. 3 sec. internal rinsing of the milk system will begin immediately after each milk-based beverage preparation.



Automatic external rinsing: An approx. 10 sec. automatic rinsing of the milk system will begin 5 min. after the last milk-based beverage preparation.



## **Milk Preparation**



Hot milk foam



Hot milk



Cold milk foam



For milk preparations, place your cup under the right hand-side outlet.

#### Milk system rinsing

The milk system is rinsed automatically in order to ensure high hygiene standards.

## **A CAUTION**

## Risk of scalding

The milk system will be rinsed automatically 5 min. after the preparation of a milk-based beverage.



Duration approx. 10 sec.

Avoid direct contact with hot water.

Protect hands from scalding.





Choose desired milk product (example Hot Milk).







Automatic internal rinsing: An approx. 3 sec. internal rinsing of the milk system will begin immediately after each milk-based beverage preparation.



Automatic external rinsing: An approx. 10 sec. automatic rinsing of the milk system will begin 5 min. after the last milk-based beverage preparation.


## **Hot Water Preparation**



Hot water



For Hot water preparations, place your cup under the left hand-side outlet.



## **△ CAUTION**

## Risk of scalding



Contact with hot fluids could result in minor or moderate injury.

Avoid direct contact with hot water.

Protect hands from scalding.







Top up or stop product dispensing within 1 min.

## **Daily Cleaning**



The display will show a reminder with a timer 2 hours before mandatory daily cleaning is required.

The machine daily cleaning is mandatory for maintaining high hygiene standards, ensuring neutral in-cup taste throughout time and for prolonging the machine life-time.

#### External cleaning

Remember to regularly inspect and, if necessary, clean the exterior of the machine.

Use a damp cloth or sponge soaked in a soap solution. Cloths and sponges must be wrung out thoroughly to ensure they are only moist, not wet, otherwise there is a risk of electric shock.


Only use mild detergents and non-scratch cloths.

Pay particular attention to the product dispensing parts. The display and keyboard must be cleaned with particular care.

#### Internal cleaning

Follow these instructions carefully to run the automatic cleaning process.







Press cleaning button.



Press the button again and hold for 3 seconds to start the cleaning.

Press any other button to exit cleaning.



Carefully remove and drain the milk container.



Carefully wipe milk suction tube with temperature sensor and level sensor, using only single-use disposable tissue or paper towel. Afterwards press any button.



Rinse milk container with potable water.

## **Daily Cleaning**



## **△** CAUTION



#### Risk of corrosive injury





Clean your hands after handling cleaning tablets.

Wear gloves/goggles.

## NOTICE

#### Cleaning solutions

The use of inappropriate cleaning solutions may damage parts of the machine or may lead to improper cleaning efficiency.

Use only Thermoplan milk cleaning tablets to perform the automatic cleaning.



Place empty container back into the refrigerator and guide the suction tube with temperature sensor and level sensor into the container. Press any button.




Remove cleaning key and insert two cleaning tablets.



Cleaning procedure starts automatically after the cleaning key is inserted.



After cleaning process the machine switches to maximum energy saving mode.





After cleaning, carefully wipe milk suction tube with temperature sensor and level sensor, using only single-use disposable tissue or paper towel. Usage of non-disposable tissue or sponge can lead to bacterial contamination of the milk.



Empty remaining water, clean milk container with potable water and place it back into the refrigerator.

## **Daily Cleaning**


# **△ CAUTION**Risk of scalding




After the cleaning procedure, remaining hot water may drop from product outlets.

Avoid direct contact with hot water.


Protect hands from scalding.



Use extraction tool to pull down coffee



Remove both coffee outlets. Properly rinse coffee outlets with fresh potable water.
Clean milk outlets with damp single-use tissue or paper towel.




Reinsert coffee outlets.




Pull out drip grids for small cups (only in vertical position) and drip tray grill.

Clean all parts.



Reinsert the drip grids for small cups.



Daily cleaning procedure completed (machine in maximum energy saving mode).

If you need to reactivate the machine, press the energy saving button as per page 16.



Drip grids for small cups can only be removed when in vertical position.

## **Weekly Cleaning**



Remove the drip grid and wash it with a soft cloth and mild detergent under running



Remove the black plastic 'plug' found in the Pull the metal frame towards you to remove.





Remove and clean the black plastic tray with a soap water solution.




Follow the above steps in reverse order to assemble the drip tray.

## **Menu Settings**

- Language setting
- Statistics
- User product counter
- Products total
- Capsule counter
- User counter reset

#### - Navigation









Escape exit menu / cancel

#### Language setting



USER MENU GENERAL SETTINGS



☑ Enter

GENERAL SETTINGS Language = English



Enter Enter





Enter

Exit menu

#### Statistics: User product counter

Press rinse button for 3 sec.

USER MENU STATISTICS

Select menu "STATISTICS"

🗹 Ente

STATISTICS
User product counter

Select "User product counter"

🗁 Ente



Espresso

← 4 2 →

Exit menu

Check "Products total" or "Capsule or counter user" (read only parameters).

#### Statistics: User counter reset

Ö

Press rinse button for 3 sec.

USER MENU STATISTICS



Select menu "STATISTICS"

Ū E

Ente

STATISTICS
User counter reset



Select "User counter reset"

**(**⊉) Ente

User counter reset

✓ no ►



Select "yes" or "no"



**⊉)** Enter



Exit menu



#### **Menu Settings**

- Milk parameters
- Milk foam settings:
  - Hot foam
  - Cold foam
- Refrigerator settings
- Cup heater

#### Milk foam settings

To change the fluidity of the milk foam, simply change the % of air in the milk foam as shown on this page:

- -10%: more liquid foam
- 0%: installation setting+10%: more solid foam

#### Milk parameter: Milk foam settings



Press rinse button for 3 sec.

USER MENU MILK PARAMETERS



Select menu "MILK PARAMETERS"



Enter

MILK PARAMETERS HOT FOAM = 0 %



Select "HOT FOAM = 0 %"



Enter

HOT FOAM = 0 %
[-10.0 .. ◀ 0 % ► .. 10.0]



Increase or decrease the amount of air in the hot milk foam if required. Range: -10 % to 10 % from default.



Enter

MILK PARAMETERS HOT FOAM = 3 %



Repeat this procedure for COLD FOAM if necessary.



Exit menu

## Milk parameter: Refrigerator settings



Press rinse button for 3 sec.

#### USER MENU MILK PARAMETERS



Select menu "MILK PARAMETERS"

(<u>□</u>) e


Enter

# MILK PARAMETERS Cooling temperature = 5.0 °C



"Cooling temperature =  $5.0 \, ^{\circ}$ C"







Increase or decrease the cooling temperature if required or set to DEFAULT (recommended).





xit menu

#### Cup heater



Press rinse button for 3 sec.

## USER MENU MACHINE PARAMETERS



Select menu "MACHINE PARAM-FTFRS"

☑ Enter

## MACHINE PARAMETERS Cup heater = On



"Cup heater = On"

**(**⊉) Ente

## Cup heater = on ◀ On ▶



Select "On" or "Off"



Enter



Exit menu

## **Menu Settings**

- AGUILA+ button programming

#### AGUILA+ button programming

The AGUILA+ button offers the choice of 13 one-touch milk-based coffee recipes. To select the one-touch recipe you would like to be dispensed when the AGUILA+ button is pressed, follow the instructions below. You can change your selection at any time by repeating the same steps.



Press rinse button for 3 sec.

USER MENU GENERAL SETTINGS



Ente



GENERAL SETTINGS AGUILA+



Ente

AGUILA+ **■** LATTE ▶



Select the desired product.



Ente



Exit men

#### AGUILA+ recipes

CORTADO LUNGO
CORTADO
FLAT WHITE
CAPPUCCINO LUNGO
CAPPUCCINO CHIARO
CAPPUCCINO FREDDO
ICED CAPPUCCINO
LATTE GRANDE
LATTE
LATTE PICCOLO
ICED LATTE
MACCHIATISSIMO
COLD MILK



See *Nespresso* Grand Cru recommendation on page 12.

## **Alarms / Notifications**

Description	Display message	LED status	Remarks
Change water filter	Change water filter Ready → Alternating	0000	Immediately call your <i>Nespresso</i> representative.
Service required	Service required Ready → Alternating	0 0 0 0 0	Immediately call your <i>Nespresso</i> representative.
Milk container empty	◆ Ready  Top up milk  Alternating	00000	Milk products are locked. Fill up milk container (in fridge).
Milk level low	◆ Ready Milk level low Alternating		Indicates that the milk container will soon be empty. Fill up milk container (in fridge).
Automatic rinsing mode (5 min. delay)	Rinsing in progress Please wait	000	Automatic rinsing of internal milk system starts 5 min. after last milk-based beverage preparation. "Rinsing in progress" and "Please wait" appear on display. LEDs start to flash 10 sec. before rinsing.
Cleaning required in x.yy h.	Ready Cleaning required in x:yy h  Alternating		When timer ends, machine will be locked until cleaned.



## **Alarms / Notifications**

Description	Display message	LED status	Remarks
Milk system cleaning required	Ready Cleaning required!  Alternating	0 0 0 0 0	Milk products not available. Start cleaning procedure as described on page 23.
Cleaning of milk system	Press 'cleaning' button for 3s to start cleaning		Start cleaning procedure as described on page 23. To quit menu, press any product button.
Milk system cleaning mode	Cleaning in progress 28:15: Please wait!		Display shows remaining cleaning time.
Milk temperature high (612 °C)	Ready Milk temperature too high  Alternating	0 0 0 0	Normal operation.  Milk products are still available but quality might be downgraded.  Replace milk with cold milk (below 6 °C).
Replace milk with cold milk (over 12 °C)	Ready Replace milk with cold milk  Alternating	0 0 0 0 0	Milk products are locked. Replace milk with cold milk (below 6 °C).
Preparation time too long	◆ Ready Preparation too long →	0000	Open lever and try to insert new capsule.


## **Alarms / Notifications**

Description	Display message	LED status	Remarks
Preparation time too short	◆ Ready Preparation too short →	0000	Open lever and try to insert new capsule. Message appears if no capsule is inserted. If message appears repeatedly, call your Nespresso representative.
Heating up boiler	← Heating up Ready → Alternating	0000	Slow flashing during heating.  If message remains for more than 30 min., call your <i>Nespresso</i> representative.
Energy saving mode	Energy Saving mode: Press any button	0000	Boiler temperature reduced.  Machine will be ready within 1 min. after pressing any product button.
Maximum energy saving mode		0000	To reactivate machine press "Energy saving" button. For more info ▶ see page 16.
Brewing unit end of life	◆ Brewing unit end of life! Ready →	0000	Immediately call your <i>Nespresso</i> representative.
CCI not connected	CCI NOT CONNECTED		All products blocked. Rinsing and cleaning still possible. Immediately call your <i>Nespresso</i> representative.

## **Specifications**


The machine can communicate with a Cash Management System.

Please contact your Nespresso representative for further information.



Power supply: 230 V / 50 Hz / 3500 W 400 V / 50 Hz / 4700 W

Dimensions:	651 x 693 x 640 mm (L / W / H)
Weight:	75 kg (empty)
	90 kg (in operation)
Outlet height standard:	190 mm
Outlet height drip grid:	92.5 mm
Water supply:	G 3/8" male
Water supply pressure:	24 bar / 3060 psi
Noise emission:	<70 dB



#### Indicative maximum product capacity per hour

Ristrettos: 240 Espressos: 200 Lungos: 140 Cappuccinos: 50 Hot water: 70

Chlorine: none

TDS: 70 to 200 ppm
Total hardness: 5-8 °dH (8-14 °fH)

pH 6.8 to 7.4

Alkalinity: less than 100 ppm lron: less than 0.25 ppm

#### **EC-Declaration**

#### **EU DECLARATION OF CONFORMITY**

We

**Thermoplan AG**, Thermoplan-Platz 1, CH-6353 Weggis, Switzerland

declare under our sole responsibility that the product

**Product** Automatic Coffee Machine

Model AGUILA Type AG220PRO

to which this declaration relates, is in conformity with the following standards and corresponding IEC standards:

EN 50366:2006 EN 61000-3-2:2009
EN 55014-1:2009 EN 61000-3-3:2008
EN 55014-2:2008 EN 61000-6-1:2007
EN 60335-1:2010 EN 61000-6-3:2011
EN 60335-2-15:2008 EN 62233:2008

EN 60335-2-75:2000 ETSI EN 301 489-1:2008 (V1.8.1)

EN 60335-2-89:2010 ETSI EN 301 489-7:2005 (V1.3.1)

EN 61000-3-11:2000 EN 301511 (V9.0.2)

EN 61000-3-12:2005

following the provisions of directives:

2011/65/EU (RoHS) 1999/5/EC (RTTED) 2004/108/EC (EMC) 2006/42/EC (MD)

This product also complies with essential safety requirements of the Low Voltage Directive:

#### 2006/95/EC

CH-6353 Weggis, 04.03.2015 Adrian Steiner, CEO

Responsible for the technical documentation is: Christian Huber

## **Type Plate**

The type plate contains the following details:

Machine type: NESPRESSO PROFESS

Coffee Machine

Model: AGUILA
Type: AG220PRO

Voltage: according to type plate
Power: according to type plate
Water Pressure: 0.2-0.4 MPa (2-4 bar)
Hvdr. Boiler: 1.46 MPa (14.6 bar)

Class: 5 (T)
Refrigerant: 134 a
Charge: 55 g
Low Side Pressure: 88 psig
High Side Pressure: 285 psiq

**Serial Number:** according to type plate **Production Date:** according to type plate

The capsule container must be removed to see the type plate.

The type plate is located beneath the capsule container on the

baseplate.



#### **Impressum**

**Version:** User Manual AGUILA 220

**Document number:** 125.971 **Revision:** A

**Technical author:** Florian Christen, www.zetavision.ch

Release date: 30. March 2015 Status: Released

Translation of the original user manual

Manufacturer: Thermoplan AG

Thermoplan Platz 1 CH-6353 Weggis Adrian Steiner, CEO Service calls:

For service calls, please contact your country specific *Nespresso* representative on

www.nespresso.com



